



TIM Impresser Repackaging for Shipment


Use the following procedures to prepare the Entrust TIM Impresser for shipment.

1. Press the power button to power off the printer.




Caution: Wait until all the lights on the front panel are off to make sure that the printer power is off.


2. Unplug the power cord from the TIM impresser (the cord is not required for shipment).




3. Remove the TIM impresser supplies.
 - a. Open the tactile impresser access door.
 - b. Remove the foil cartridge (the cartridge is not required for shipment).



4. Remove the TIM impresser from the printer.
 - a. Reach inside the TIM impresser towards upper front section and push in on the release latch.
 - b. Pull out the TIM impresser from the printer.
 - c. Close the TIM impresser access door.



5. Pack the TIM impresser.
 - a. Place the TIM impresser on the folding container and close the sides of the container.



- b. Place the end caps into the folding container.
- c. Lift the folding container using the handle cut outs and place the container in the box.
- d. Place the accessories tray in the box.
- e. Close and secure the box with shipping tape.

